

ISTEC Series

Clean Tube Cutter for Stainless tubes & pipes







ISTEC340



ISTEC Series 200/340

1. FEATURES


Best suitable to cut stainless steel pipe cleanly for such as semiconductor equipment.


As cutting fluid is not used, cleaning after cutting is not required.

The cut edge surface is precise and clean. Surface finishing of the edge is higher grade.

The outer cutting edge is free of burrs. Internal burrs can be removed easily with an accessory tool.

Being compact and light in weight, this Tube Cutter feasible for carrying. (ISTEC200)





2. SPECIFICATIONS

ТҮРЕ		ISTEC200		ISTEC340				
		Size	Thickness	Tube Size	Thick	Pipe Size	Thick	
Name of Cutting		1/4 (ф6.35)	0.89~1.0mm	3/4 (ф19.05)		10А (ф17.3)		
Normal C	J	3/8 (ф9.52)	1.0mm	1 (φ25.4)	2.1mm	15A (ф21.7)	2.1mm	
Tube • Pipe Size & Thickness		1/2 (φ12.7)	1.2~1.25mm		or less	20A (φ27.2)	or less	
						25А (ф34.0)		
Option		Corresponding to Option						
		Size	Thickness	※Possible to cut Intermediate size of the above . Inquire us for the details.				
		1/8 (ф3.18)	0.5~0.72					
Applicable tube material		316L SS, 316 SS, 304 SS						
Weight		5.9kg		20kg				
Motor	Voltage	AC100V±10% Note: Supports each country voltage					oltage	
	Frequency	50/60Hz						
	Work temp.	-10∼40°C						
Outside dimension (WxHxD)		228 x 207 x 210 (mm)		420 x 330 x 290 (mm)				

3. STANDARD ACCESSORIES / OPTIONS


Туре		ISTEC 200	ISTEC 340	
	Cutting Blade	3 pcs./set %Note1	3 pcs./set	
	Blade holder%Note3	1/4, 3/8, 1/2 1 pc each (total 3 pcs)	3/4- 1pc ※Note 2	
	Adapter ※注3	1/4, 3/8 1 pc each (total 2 pcs)	3/4- 1cs	
Standard	Internal burr remover Note4	1/4, 3/8, 1/2 1 pc each (total 3 pcs)	×	
Stallualu	Hexagon wrench	2.5, 3, 5mm 1 pc each (total 3 pcs)	2.5mm 1 pc	
	Tool box	1 box	1 box	
	Instruction manual	1 volume	1volume	
	Driving belt	1pc	1 pc	
	Chips receiver	1pc	1 pc	
	Blade	10 pcs./set %Note1	10pcs/set %Note 1	
Option	Length measuring scale	0	×	
(Sold separately)	Chips receiver	○ ※Note 5	○ ※Note5	
	Cut piece receiver	×	0	
Option for 1/8 (Sold separately	Standard set	Blade:1pc, Tube adapter:1pc Blade holder:1 pc, Burr remover:1pc		
	Cutting blade	10 pcs./set		


- \times Note1: Cutting blades for 1/4, 3/8, and 1/2sizes are common (ISTEC200). 3/4, 1, 10A, 15A, 20A, 25A are common (ISTEC340)
- XNote 2: Standard accessory is 3/4. Other sizes of 1, 10A, 15A, 20A, and 25A are options. ★
- ※Note 3: Blade holder and Adapter are required for each size.

No adapter is required for 1/2 inch of ISTEC 200.

- %Note 4: Internal burr remover is for 1/4(inch)→ Thickness 1mm, 1/2(inch)→Thickness 1.24mm. (ISTEC200)
- *Note 5: Available 1 piece as standard accessory . Also available for option as well.

4. OUTSIDE DIMENSION





You can get more information through Website.

http://www.ihara-sc.co.jp/en

◆Head Office

11-3 Takanawa 3-chome Minato-ku, Tokyo 108-0074 Japan TEL: +81-3-6721-6981 FAX: +81-3-6721-6991

- ♦IHARA SCIENCE TAIWAN Co., Ltd No.79, Mingyi St., West Dist. Taichung City 403, Taiwan (R.O.C.) TEL:+886-4-2319-1116 FAX:+886-4-2319-1126
- ♦IHARA KOREA Co.,Ltd Digital Empire II 103-905, Sinwon-ro 88, Yeongtong-Gu, Suwon-Si, Gyeonggi-Do, 443-734. South Korea TEL:+82-31-695-6800 FAX:+82-31-695-6808
- ◆NANTONG IHARA SCIENCE Co., Ltd. GP Div.: No.26-4 Tongsheng Road, (CP Div.: No.1692 Bldg, N0.8 Xinghu Road,) Economic & Technological Development Zone, Nantong, Jiangsu 226010 P.R.China TEL:+86-513-8152-0189FAX:+86-513-8152-0189
- ♦ IHARA SCIENCE USA CORPORATION 17971 Sky Park Circle, Suite B, Irvine, California 92614 U.S.A. TEL:+1-949-387-3727 FAX: +1-949-387-3739

WARNING

If you don't select and handle fittings, valves and related accessories in an adequate manner, it may damage human beings and applicable systems. Within the responsibility and authorization of users and piping designers, fittings, valves and related accessories shall be adequately selected, used and maintained based

on the applicable conditions and product conformity to the system to be applied. Please read carefully the operation manual and feel free to contact with Ihara if you have any question or request.

WARRANTY CLAUSE

1. Warranty Period

The warranty period of the products is one (1) year from putting into service or one and half (1.5) years after delivery whichever comes earlier. However, the products specially specified and/or the cases used under deviating from the specification shall be exempted.

2. Scope of Warranty

Any failure and damage under maker's responsibility will be found during the warranty period, the substitute and/or replacement parts shall be provided at no charge. The warranty means the warranty of the products of our company. Any liquidated damages caused by the failure or damage of our product shall be exempted from the scope of the warranty.

■The contents of this leaflet are subject to change without notice.